STRAIGHT LINE DIAGRAMS

WITH SUPERELEVATION AND DESIGN SPEED

Roadway Design Process


The Roadway Designer must establish what are the features of the existing roadway such as the superelevation of any horizontal curve.

- The Designer must determine the Design Speed which is the principle controlling element for determination of all additional design criteria.
- By having the Horizontal Curve Superelevation values and Design Speed included in the SLDs, this cuts down on time consumed on searching for as-builts and/or design documentation from previous projects.


WHAT, WHERE & HOW

- What are the features on the SLDs that are uploaded from the RCI database that is associated with the data being used?
- Where is this data located on the SLD?
- ▶ How is it being gathered?
- ► How is it displayed on the SLD?


Current D7 Straight Line Diagram (SLD)



Roadway Features



FEATURES WHAT & WHERE



DESIGN SPEED

> Typical Section Package. Usually available around 30% submittal and includes the posted speed limit.

(Posted Speed is approved by the Traffic Operation Engineer Design speed is approved the District Design Engineer.)

Construction Plans

FEATURE 311

▶ This is a Traffic Operations feature. A new characteristic should be added to feature 311 for the design speed.

SLD with Curve Data

ROAD	Roadway 10020000 Descriptio		Man-Dist: 07 BUS.US41	Geo-Dist: 07	County: HILLSBOROUGH	Beg. MP: 0.000	End. MP: 11.211	1	et Length: 1.211 ideoLog		Overall Status: ACTIVE ON THE SHS Enterprise GIS	0.000 E 7 AVE
FEATU	Feature	220 - NO	N CURVE INT	ERSECTION POINT							POINT/NON-INTERLOCKING	3
	Beg.	MP	End. MP		Characteristic		Value	Unit	Side	Offset	Char. Updated	
LANI ARE		0.821 NONCURVE PT OF INTERSECTION		000D0	1'01.00"	DE	С	L	RCICNVRT 04/26/1999			
ANE		1.328	<u>N</u>	ONCURVE PT OF INTER	SECTION	000D0	3'07.00"	DE	С	L	RCICNVRT 04/26/1999	
		1.833	<u>N</u>	ONCURVE PT OF INTER	SECTION	000D0	0'27.00"	DE	С	L	RCICNVRT 04/26/1999	
INVEN		2.337	<u>N</u>	ONCURVE PT OF INTER	SECTION	000D0	3'06.00"	DE	С	L	RCICNVRT 04/26/1999	
DIREC		2.839	<u>N</u>	ONCURVE PT OF INTER	SECTION	000D0	0'37.00"	DE	С	L	RCICNVRT 04/26/1999	
RO		3.348	<u>N</u>	ONCURVE PT OF INTER	SECTION	000D0	0'26.00"	DE	С	R	RCICNVRT 08/11/1999	
сом		5.337	<u>N</u>	ONCURVE PT OF INTER	SECTION	000D1	4'06.00"	DE	С	R	RCICNVRT 08/11/1999	
	ZONTAL	=N21°08'29	A NOT FIELD VERI	FIED		PC=0,389 Pl=0,407 PT=0,425 A=21°38'23,00" D=11°31'22,98" B=N	00°29'55"F				Δ=0°01'01.00" PI=0.821 B=N00°2	28'54"F
	UCTURE CRIPTION								0, #110 23, 0, #10 0, #	UP 1832 0.0 633 84 0.0	#651 O 42' UP	
	8 us	SB 41/SR 60 -	- RDWY ID 10080101									
DISTE	RICT USE S FI	M# 255454-15 M# 255507-15	5201 (MP 0.000 - MP 4 5201 (MP 0.000 - MP 2	3.136) 1984 - STATE RESUR 4.300) 1984 - STATE RESUR 2.961) 2000 - RESURFACINO 3.239) 2013 - RESURFACINO	FACE/REPAVE							
	SIS											
FUN	CLASS 8 UF	RBAN MINOR	RART									
SPE	ED LIMIT 8 35	мрн										

FEATURE 220 DESCRIPTION

Non Curve Intersection Point - Feature 220

RCI Features & Characteristics Handbook

Owning Office: Planning TranStat

NCPTINT

Non Curve Point of Intersection

Roadside: C/R/L Feature Type: Point

Definition/Background: Denotes the intersection point without point of curvature or point of tangent, to accommodate minor survey changes, a change in the direction of the roadway, or 90° turns, right or left, at an intersecting roadway.

Responsible Party for Data Collection: District Planning

Required For: All functionally classified roadways on the SHS

Who/What uses this Information: Central Planning, District Planning



Important When Gathering: This is a point feature; therefore, it only has a single milepoint. When inventorying make note of the offset, e.g. left or right. This information may be obtained from construction plans.

How to Gather this Data: In office - Refer to most recent construction plans. Enter in degrees/minutes/seconds. Refer to coding box.

Offset direction: 2-right, 3-left

Special Situations: Non-curve data must be coded for left and right side when coding divided roadways.

Value for Non Curve Point of Intersection: 13 Bytes: XXXDXX'XX.00" - Degrees/minutes/seconds

Enter using the following format:

			D			,				0	0	"	Format
1	2	3	4	5	6	7	8	9	10	11	12	13	Position

Below are descriptions for the byte positions:

- 1-3 number of degrees
- D for degrees
- 5, 6 minutes
- 7 single quote (') for minutes
- 8, 9 seconds
- 10-13 .00"

SLD with Curve Data

\$ 5		4					1 1	41 68	85	0 -	# 11	#83			٥ <u> </u>
DWAY DWAY	0.054 MADISO STE	0.110 TWIGG STE	0.167 ZACK S	0.220 POLK S	0.275 CASS S	0.330 TYLER	0.385	0.472 E FORT	0.536 E LAUR	(1-WAY	0.604 SCOTT	0.639	0.743 E ESTE E KAY ((1-WAY 0.669	0.821 E HEND AVE	
TURES	Roadway ID: 10020000	Man-Di 07	ist: Go	eo-Dist:	County: HILLSBOF	DOLIGH	Beg. M 0.000	P: End.	. MP:	Net L 11.21	ength:		Overall Status: ACTIVE ON THE SHS		
E WIDTHS	Description: SR-68	•	01		TILLODOF	COOGII	0.000	11.2	.11	Video			Enterprise GIS		
C	Validate						Show Deta	ils						Previous Next	
NTORY N	Feature 221 - H	ORIZONTAL	CURVE										LEN	GTH/INTERLOCKING	;
	Beg. MP	End. MP			Characterist	ic		Value)	Unit	Side	Offset	Char. U	lpdated	╛
ROADWAY S	0.000	0.389	COMPASS BEA	<u>ARING</u>				N21D08'29"W		DE	С		RCICNVRT	08/11/1999	┵
OMPOSITION	0.389	0.425	HORIZONTAL C	CURVE CENT	TRAL ANGLE			021D38'23.00"		DE	С	R	RCICNVRT	04/03/2000	
			HORIZONTAL D	EGREE OF	CURVE			011D31'22.98"		DE	С	R	RCICNVRT	02/09/2001	
ORIZONTAL			HORIZONTAL P	T. OF INTER	RSECTION			0.407		MI	С		RCICNVRT	04/26/1999] -
LIGNMENT	0.425	0.821	COMPASS BEA	<u>ARING</u>				N00D29'55"E		DE	С		RCICNVRT	08/11/1999	
	0.821	1.328	COMPASS BEA	<u>ARING</u>				N00D28'54"E		DE	С		RCICNVRT	08/11/1999	28'5
	1.328	1.833	COMPASS BEA	<u>ARING</u>				N00D20'47"E		DE	С		RCICNVRT	08/11/1999	11
TRUCTURE	1.833	2.337	COMPASS BEA	ARING				N00D20'20"E		DE	С		RCICNVRT	08/11/1999	11
ESCRIPTION	2.337	2.839	COMPASS BEA	ARING				N00D12'14"E		DE	С		RCICNVRT	08/11/1999	11
ESCRIPTION	2.839	3.348	COMPASS BEA	<u>ARING</u>				N00D11'37"E		DE	С		RCICNVRT	08/11/1999	11
9	3.348	5.337	COMPASS BEA	ARING				N00D12'03"E		DE	С		RCICNVRT	08/11/1999	11
	5.337	5.840	COMPASS BEA	ARING				N00D26'09"E		DE	С		RCICNVRT	08/11/1999	1=
ISTRICT USE	5.840	6.343	COMPASS BEA	ARING				N00D27'12"E		DE	С		RCICNVRT	08/11/1999	16
010	6.343	6.617	COMPASS BEA	ARING				N00D27'00"E		DE	С		RCICNVRT	08/11/1999	1
SIS	6.617	6.875	COMPASS BEA	ARING				N00D27'21"E		DE	С		RCICNVRT	08/11/1999	1
UN CLASS S	6.875		COMPASS BEA					N00D27'04"E		DE	С		RCICNVRT	08/11/1999	11
SPEED LIMIT &	7.381		COMPASS BEA					N00D22'14"E		DE	С		RCICNVRT	08/11/1999	1L
	1.381	7.000	COMPASS BEA	<u>ARING</u>				N00D22 14 E		DE	C		RUUNVKI	06/11/1999	

FEATURE 221 RCI FEATURES & CHARACTERISTICS HANDBOOK

COMPASS BEARING

HORIZONTAL CURVE

HORIZONTAL DEGREE OF CURVE

Horizontal Curve - Feature
RCI Features & Characteristics Handbook Owning Office: Planning Tra

BEARING Compass Bearing

Roadside: C/R/L. Feature Type: Length

Interlocking: Yes

Definition/Background: Represents a directional line segment of the roadway showing the degree of curvature of the roadway and bearing changes effected by curves in the roadway and/or horizontal shifts in the roadway.

Responsible Party for Data Collection: District Planning

Required For: All functionally classified roadways on the SHS

Who/What uses this Information: Safety, Central Planning, District Planning

How to Gather this Data: In office - Refer to construction plans or survey field book.

Enter N or S, the degrees/minutes/seconds, and the direction of deviation. Determine the angle deviation from north or so and the direction of the deviation.

Code using the described format. For example, a roadway heading 29 degrees in an eastward direction from north would a deviation description of "N 29" E," and a roadway 35 degrees from south in a westward direction would be "S 35" W."


Value for Compass Bearing: 11 Bytes: XXXDXX'00'X - Record curve degrees/minutes/seconds

Enter using the following format:

			D			,	0	0	"		Format
1	2	3	4	5	6	7	8	9	10	11	Position

Below are descriptions for the byte positions:

- 1 N (north) or S (south)
 2, 3 the number of degrees the roadway turns
- the number of degrees the roadway
 D for degrees
- 5 6 minutes of the curve
- 7 single quote (') for minute
- 8, 9 seconds of the curve
- 11 direction in which the curve is traveling: E (east) or W (west)



RCI Features & Characteristics Handbook

Horizontal Curve - Feature 2: Owning Office: Planning Trans

HRZCANGL Horizontal Curve Central Angle

Roadside: C/R/L Feature Type: Length Interlocking: Yes

Definition/Background: Denotes the roadway segment's central curve angle. Also commonly referred to as the delta (Δ)

PI - Point of Intersection. The point where the back and forward tangents intersect.

Central Angle – Angle formed by two radii drawn from the center of the circle to the PC and PT. Also referred to as the de (Δ).

Responsible Party for Data Collection: District Planning

Required For: All functionally classified roadways on the SHS

Who/What uses this Information: Safety, Central Planning, District Planning

How to Gather this Data: In office – Refer to construction plans or survey field book. Enter degrees/minutes/seconds. R to coding box.

Offset direction: 1-right and left, 2-right, 3-left


Value for Horizontal Curve Central Angle: 13 Bytes: XXXDXX'XX.00" - Record angle according to degrees/minutes/seconds /hundredths of a second

Enter using the following format:

			D			,				0	0	20	Format
1	2	3	4	5	6	7	8	9	10	11	12	13	Position

Below are descriptions for the byte positions:

- 1-3 will be the number of degrees of the angle (zero fill degrees; e.g., 005 for 5 degrees)
- will always be D for degrees
- 5, 6 will be the minutes of the curve
- will always be a single quote (') for minutes
- , 9 will be the seconds of the curve
- 10-12 will always be .00 (optional may be removed)
- 13 will always be a double quote (") for seconds



RCI Features & Characteristics Handbook

Roadside: C/R/L

Horizontal Curve - Feature 221
Owning Office: Planning TranStat

HRZDGCRV Horizontal Degree of Curve

Feature Type: Length Interlocking: Yes

Definition/Background: Denotes the degree of curvature per 100 feet. Sometimes referred to as the D value of the curve.

The horizontal degree of curve is used to calculate the CURCLASx (x = A-F) in Feature 118 (HPMS).

The degree of curvature is measured by the angle subtended at the center by an arc 100 feet long.

Small D values represent flat curves with large radii, and large D values represent sharp curves with small radii. In general, D values larger than 20° are rare.

Responsible Party for Data Collection: District Planning

Required For: All functionally classified roadways on the SHS

Who/What uses this Information: Safety, Central Planning, District Planning

How to Gather this Data: In office - Refer to construction plans or survey field book.

Offset direction: 1-right and left, 2-right, 3-left

Enter degrees/minutes. Refer to coding box. The horizontal degree of curve should be coded for both sides of the roadway for all divided roadways that have different alignments.


Value for Horizontal Degree of Curve: 7 Bytes: XXXDXX' - Record degrees/minutes

Enter using the following format:

			D			,	Format
1	2	3	4	5	6	7	Position

Below are descriptions for the byte positions:

- 1-3 will be the number of degrees the roadway turns
- 4 will always be D for degrees
- 5. 6 will be the minutes of the curve
- 7 will always be a single quote (') for minutes



CURVE DATA
PI STA = 406+00.58

DELTA = 18° 02' 46" (RT)
D = 1° 30' 00"
T = 606.56'
L = 1,203.07'
R = 3,819.72'
PC STA = 399+94.03
PT STA = 411+97.10

SUPERELEVATION

- > For new roadway construction and reconstruct project.
- > This information can be found in construction plans on the Roadway Profile sheets.

Question?

How do we show this in the RCI database and on the SLD?